



# WIRING DIAGRAM

**FIGURE 1:** OPENS ON TEMPERATURE DROP (HEAT)




\*MUST CLIP COOLING ANTICIPATOR FROM BACK OF THERMOSTAT

**FIGURE 2:** OPENS ON TEMPERATURE RISE (COOL)



\*MUST CLIP COOLING ANTICIPATOR FROM BACK OF THERMOSTAT

**FIGURE 2:** OPENS ON TEMP RISE OR FALL (HEAT AND COOL)



\*MUST CLIP COOLING ANTICIPATOR FROM BACK OF THERMOSTAT

 <b>EWC</b> <sup>®</sup> CONTROLS INC. Englishtown, NJ 07726	DWN ENG: EDK		DWG NAME: MODEL ND/URD -- WIRED W/ EWT AND TSB	
	SIZE: A	DATE: 01/22/04	DWG NO: 090512A0045	REV: A
	SCALE: NOT TO SCALE	COPYRIGHT © EWC CONTROLS INC. ALL RIGHTS RESERVED		SHEET: 1 OF 1